




DSR – DUCT OPTION INSTALLATION

For the air inlet:
Push buttons down




Open inlet grille




Lift off and remove




Offer-up the duct adapter






Locate into pivot tabs

Close (latches lock automatically)
Now ready to fit ducting (315mm dia)



For air outlet



Offer-up outlet ring to
Outlet grille



Mode State:DUCTS(+)

ance:GENERIC

Secure into place with 6 screws
Now ready to fit ducting (315mm dia.)

